



BIOS Setup

OptiPlex 3060 Thin Client

Advanced
Setup☒ ON

Help Test

☒ ON

Admin

Password

Overview

Boot Configuration

Integrated Devices

Storage

Display

Connection

Power

Security

Passwords

Update/Recovery

System Management

Keyboard

Pre-boot Behavior

Virtualization Support

Performance

System Logs

About

Storage

SATA/NVMe Operation

SATA/NVMe Operation

Set the operating mode of the integrated storage device controller.

Storage Interface

Port Enablement

Please select onboard storage to enable.

This page allows you to enable the source of onboard storage visible to operating system.

☒ M.2 PCIe SSD☐ Onboard eMMC

SMART Reporting

Enable SMART Reporting

If S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) is enabled, the BIOS can receive analytical information from integrated drives and send notifications during startup about possible future failure of the hard drive.

If SMART Reporting is enabled, hard drive errors for integrated drives will be reported during system startup.

☐ OFF

Drive Information

M.2 PCIe SSD

LOAD DEFAULTS

APPLY CHANGES

Changes were made

EXIT