



1. Check in
ExpressPoll finds the voter in the electronic pollbook, identifies the voter's correct ballot style and sends the information to the ExpressVote Printer.

2. Receive ballot
The voter's correct ballot style is printed onto an ExpressVote activation card that is then given to the voter.

00000001

DEMO COUNTY/DEMO STATE
DEMONSTRATION ELECTION
11/05/2024

PRECINCT 001, BALLOT STYLE 001

3. Vote
The voter inserts the card into the ExpressVote XL Universal Voting System to make her selections and cast her ballot.

