

How to Measure Your Horse to Fit into the Correct HUG Blanket

Three things determine the approximate fit of a HUG blanket:

- #1 The requirements of your horses neck and shoulders **(A)**
- #2 The length of his back **(B)**
- #3 The drop length which will cover him completely. **(D)**

(A) Neck sizes are taken completely around the horse's neck from in front of withers along the shoulder line.

(B) Back measurements are taken from in front of withers to base of tail.

(C) Chest to tail measurements from center of chest to point of buttocks

(D) Drop measurements are taken from 12 inches behind withers to desired length to cover the horses' sides.




Neck Size	Measures
Medium	47" to 52"
Large	50" to 56"
Xlarge	54" to 60"
XX Large	58" to 64"
XXX Large	62" to 68"
XXXX Large	66" to 72"

1) Take measurements A, B and D

2) Using the chart to the left, decide which size neck your horse has (medium, large, Xlarge etc)

3) Using the chart below, plug in your measurements and decide which HUG will fit your horse perfectly!



LuckyPony.com
your source for hug sheets,
blankets, and accessories

Size (Chest to Tail)	70	72	74	76	78	80	82	84	86	88	FA*	FB*
Neck Size (A)	Medium	Medium	Large	Large	X Large	X Large	X Large	XX Large	XX Large	3X Large	3X Large	4X Large
Back Length (B)	48	50	50	52	52	54	56	56	58	58	53	53
Drop (D)	32	33	34	35	36	37	37	38	38	39	37	38