


Display and control panel



- 1- Enables the setting value of Cooler to be modified and Super Cool Mode to be activated if desired. Cooler may be set to 8, 6, 5, 4, 2 °C, SC.
- 2- Enables the setting value of Freezer to be modified and Super Freeze Mode to be activated if desired. Freezer may be set to -16, -18, -20, -22, -24 °C, SF.
- 3- Enables the modes (Economy, Holiday...) to be activated if desired.
- 4- Child Lock and Sound Alarm Off Button.
- 5- Cooler Set Value Screen.
- 6- Super Cool Indicator.
- 7- Holiday Mode Symbol.
- 8- Low Voltage Warning Symbol.
- 9- Drink Cool Mode Time Value Screen.
- 10- Freezer Set Value Screen.
- 11- Super Freeze Indicator
- 12- Alarm Symbol
- 13- Economy Mode Symbol
- 14- Demo Mode Symbol
- 15- Child-Lock Symbol