

CANON ERROR CODE
KODE EROR FOTOCOPY CANON NP-IR-GP-FC

BRAND	MODEL	ERROR CODE	MOST LIKELY CAUSE
CANON	155	E0	The fusing unit does not heat up
CANON	155	E1	The sensor motor or sensor, the DC controller on the main board DC controller
CANON	155	E2	The copyboard position sensor
CANON	155	E4	Main motor, Main motor PCB, DC controller
CANON	155	E5	Lens home position error
CANON	155	E6	Exposure lamp control PCB, light intensity error, DC controller
CANON	155	E7	Main motor PCB, DC controller
CANON	155	E8	Counter error
CANON	155	E9	AC drive board, DC controller
CANON	155	EC	Copy board drive lock
CANON	155	ED	Operation panel
CANON	155	EE	Main motor drive board, DC drive board
CANON	FC330	E0	The fusing unit does not heat up
CANON	FC330	E1	Fusing film damaged or out of position
CANON	FC330	E2	Copy board drive lock or home position error
CANON	FC330	E6	Blown exposure lamp or exposure lamp terminals bad contact
CANON	720, 740, 750, 770	C	Fusing film damaged or out of position the machine tries to compensate
CANON	720, 740, 750, 770	H	Fusing unit overheating
CANON	720, 740, 750, 770	E0	The machine was switched OFF and ON after one of the E00X error codes
CANON	720, 740, 750, 770	E000	Bad thermistor, thermofuse, fusing element, triac or power supply