






Home Insert Annotate Parametric View Manage Output Add-ins Collaborate Express Tools ANSYS 2021 R1 Featured Apps



Scale

Enlarges or reduces selected objects, keeping the proportions of the object the same after scaling

To scale an object, specify a base point and a scale factor. The base point acts as the center of the scaling operation and remains stationary. A scale factor greater than 1 enlarges the object. A scale factor between 0 and 1 shrinks the object.



Press F1 for more help

Scale Tool



AUTOCAD