

Prime FLASHPAD

Instruction Manual

⚠ WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 yrs.

GETTING STARTED:



GAME SELECT MODE:



BATTERY INSTALLATION:

1
2
3

VOLUME SETTINGS:

SCORE MEMORY RESET / CHECKING THE HIGH SCORE:

SCORE MEMORY RESET:

CHECKING THE HIGH SCORE: